Panasonic

Supplied software

Introduction

- **In these operating instructions, supplied software included in the CD-ROM is described.**
- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation, USA in the United States and other countries.
- Apple, the Apple logo and Macintosh, Mac OS are the registered trademarks of the Apple Computer, Inc., USA.
- Adobe, the Adobe logo and Adobe Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and other countries.
- Intel, Pentium, and Celeron are either registered trademarks or trademarks of Intel Corporation in the United States and other countries.
- Further, various names, organization names, products etc. mentioned herein are the registered trademarks or trademarks of respective organizations
- Please note that some of the explanations and screens covered in these operating instructions may differ from actual ones depending on the operating environment of the PC.
- No information is provided about basic PC operations and terms. Please refer to the relevant PC manual.
- The explanations of these operating instructions are subject to change without prior notification.
- No part of these operating instructions may be reproduced without permission.

Features

As for LUMIX Simple Viewer, refer to the "Operating Instructions For Digital Camera PC Connection".
For details about the supplied software and user support, please refer to the Help files for the respective software.

- Even when the operating environment is satisfied, the product cannot be used on some PCs.
- When 2 or more USB devices are connected to 1 PC, or when the product is connected to the PC through a USB hub or a USB extension cable, operation is not guaranteed.
- When connected to the USB terminal of the PC keyboard, the product might not operate properly.

Panasonic

Logiciel fourni

Introduction

- **Dans ce manuel d'instructions, les logiciels fournis inclus sur le CD-ROM sont décrits.**
- Microsoft et Windows sont chacune des marques de fabrique ou des marques déposées de Microsoft Corporation, USA aux États-Unis et dans d'autres pays.
- Apple, le logo Apple et Macintosh, Mac OS sont des marques déposées de Apple Computer, Inc., USA.
- Adobe, le logo Adobe et Adobe Reader sont chacune des marques déposées ou des marques de fabrique d'Adobe Systems Incorporated aux États-Unis et dans d'autres pays.
- Intel, Pentium, et Celeron sont chacune des marques déposées ou des marques de fabrique d'Intel Corporation aux États-Unis et dans d'autres pays.
- De plus, les différents noms, noms d'organisation, produits etc. mentionnés ici sont des marques déposées ou des marques de fabrique de leur respective organisation.
- Veuillez noter que certaines explications et certains écrans décrits dans ce manuel peuvent être différents de la réalité selon le système d'exploitation de l'ordinateur.
- Aucune information n'est fournie sur la durée ou le fonctionnement de base du PC. Veuillez vous référer au manuel qui se rapporte à l'ordinateur.
- Les explications de ce manuel d'instructions sont sujet à changement sans avis préalable.
- Aucune des parties de ce manuel ne peut être reproduite sans permission.

Caractéristiques

Quant au LUMIX Simple Viewer, référez-vous au "Manuel d'utilisation pour le raccordement de l'appareil photo numérique au PC".
Pour des détails à propos du logiciel fourni et de l'assistance à l'utilisateur, veuillez vous référer aux fichiers Aide du logiciel.

- Même si l'environnement du système d'exploitation est suffisant, le produit ne peut pas être utilisé sur certains ordinateurs.
- Lorsque 2 ou plus périphériques USB sont branchées à 1 PC, ou lorsque le produit est branché au PC à travers une prise USB ou un câble d'extension USB, le fonctionnement n'est pas garanti.
- S'il est raccordé à la prise USB du clavier de l'ordinateur, le produit ne fonctionne pas correctement.

ArcSoft Software Suite (Editing and processing software)

ArcSoft PhotoBase
Software which enables catalogue-making by bundling files together containing still pictures, etc.

ArcSoft PhotoImpression
Editing, processing and printing of still pictures can be done. Pictures can be stored in albums.

ArcSoft Panorama Maker
It is possible to combine several still pictures to make panoramic photos.

QuickTime (Picture playback software) (Windows 2000/XP only)

To play back motion pictures recorded with digital camera (motion JPEG format: file extension .mov).

- If you use Windows 98/98SE/Me, download "QuickTime 6.5.2 for PC" from the following site and then install it.
  http://www.apple.com/support/quicktime/

Adobe Reader (Windows only)

To view the installed operating instructions.

Installing supplied software

(For Windows)

1 Insert the CD-ROM.
The setup menu will start.
(When using the CD-ROM included in the digital camera: DMC-FX07)

2 Click on the software icon to install.
- Proceed with installation according to messages appearing on the screen.

(For Macintosh)

1 Insert the CD-ROM.
The folder is automatically displayed.

2 Double-click the ArcSoft folder to open it.
① Select an application folder.
② Double click on the icon in the application folder.
- Installation starts.

- For information about how to use the supplied software, refer to the PDF manual or help section for each software application.

Operating environment

ArcSoft Software Suite (PhotoBase, PhotoImpression and Panorama Maker)

PC:	**[For Windows]** IBM® PC/AT compatible PC having Pentium III or more recommended (included compatible CPU) **[For Macintosh]** iMac, iBook, Power Mac G3 or more, PowerBook G3 or more
OS:	**[For Windows]** Windows 98SE Windows Me Windows 2000 Windows XP Home Edition Windows XP Professional **[For Macintosh]** Mac OS 9.x Mac OS X
Graphics display:	High Color (16 bit) or more Desktop environment 800×600 or more
Random Access Memory:	**[For Windows]** 128 MB or more **[For Macintosh]** 128 MB or more
Hard disk:	**[For Windows]** 500 MB or more free space **[For Macintosh]** 400 MB or more free space
Disk drive:	CD-ROM drive
Connection terminal:	USB (A type)
Others:	Mouse or equivalent pointing device

QuickTime*

OS:	Windows 2000 Windows XP Home Edition Windows XP Professional

Adobe Reader*

OS:	Windows 98SE Windows Me Windows 2000 SP2 Windows XP Home Edition Windows XP Professional

* See the web site about QuickTime and Adobe Reader.
(QuickTime: http://www.apple.com) (Adobe Reader: http://www.adobe.com)

Caution for Use

- Please do not disconnect the USB connection cable when Software (supplied) is in use. The software may not function correctly and damage the data being transmitted.
- When the card access indication of the digital camera is lit or flashing, please do not disconnect the USB connection cable. The software may not function correctly and damage the data being transmitted. Please refer to the digital camera operating instructions.
- When connecting to a PC, use an AC adaptor (optional) as the digital camera power source. If the battery is disconnected during data transmission, there will be the risk of damage to the data being transmitted.
- If you insert a Memory Card which is not for use with the digital camera, it may not be recognized by the Software (supplied). In such cases, although it is possible to properly recognize it by formatting with the digital camera, please be careful since the data saved in the Memory Card will be deleted.
- When you play pictures with audio or motion pictures with QuickTime, the message "No Disk" may appear on the screen. In this case, press [Cancel] button displayed with the message. This occurs because QuickTime attempts to confirm the files you have never played. This is not a malfunction. If you select [File] >> [Open Recent] and then execute [Clear Menu] on QuickTime, the history of the files you have never played will be deleted.

QuickTime

QuickTime and the QuickTime logo are trademarks or registered trademarks of Apple Computer, Inc., used under license.

Panasonic Consumer Electronics Company,
Division of Panasonic Corporation of North America
One Panasonic Way, Secaucus, NJ 07094

Panasonic Puerto Rico, Inc.
Ave. 65 de Infantería, Km. 9.5, San Gabriel Industrial Park, Carolina, Puerto Rico 00985

Panasonic Canada Inc.
5770 Ambler Drive, Mississauga, Ontario, L4W 2T3

© 2006 Matsushita Electric Industrial Co., Ltd.

P

Précautions d'utilisation

- Veuillez ne pas débrancher le câble USB lorsque le logiciel (fourni) est en cours d'utilisation. Le logiciel peut ne pas fonctionner correctement et endommager les données qui sont transmises.
- Lorsque l'indicateur d'accès à la carte est allumé ou clignote, veuillez ne pas débrancher le câble USB. Le logiciel peut ne pas fonctionner correctement et endommager les données qui sont transmises. Veuillez vous référer au manuel d'instructions de l'appareil photo numérique.
- Pour la connexion à un PC, utilisez un adaptateur secteur (en option) telle que la source d'énergie de l'appareil photo numérique. Si la batterie est débranchée pendant la transmission des données, il y a le risque d'endommager les données transmises.
- Si vous insérez une carte mémoire qui n'est pas faite pour l'utilisation avec l'appareil photo numérique, il se peut qu'elle ne soit pas reconnue par le logiciel (fourni). En pareil cas, bien qu'il soit possible de la reconnaître correctement en la formatant avec l'appareil photo numérique, veuillez faire attention car les données sauvegardées sur la carte mémoire seront effacées.
- Lorsque vous visualisez des images avec son ou des images animées avec QuickTime, le message "No Disk" apparaît à l'écran. Dans ce cas, appuyez sur le bouton [Cancel] affiché avec le message. Ceci survient car QuickTime tente de confirmer les fichiers que vous n'avez jamais visualisés. Ce n'est pas un mauvais fonctionnement. Si vous sélectionnez [File] >> [Open Recent] et puis si vous exécutez [Clear Menu] dans QuickTime, l'historique des fichiers jamais visualisés sera effacé.

QuickTime

QuickTime et le logo QuickTime sont des marques de commerce ou des marques déposées de Apple Computer Inc. et sont utilisées sous licence.

Panasonic Canada Inc.
5770 Ambler Drive,
Mississauga, Ontario
L4W 2T3
(905) 624-5010
www.panasonic.ca

© 2006 Matsushita Electric Industrial Co., Ltd.

K

Imprimé au Japon